

Brazil East

V4.15.03 Update: 03 JUN 2012


NOT FOR NAVIGATIONAL PURPOSES

Further Details: www.planningcharts.de
 Contact: feedback@planningcharts.de

ICAO	Airport	APP	RWY	ELEV	VAR	RFF
SBBE	Belem	I06 G24 G02 G20	2.8 1.8	54	20W	8
SBBH	Belo Horizonte	I16 G34	3.0	2715	22W	9
SBBR	Brasilia	I11L I29R I11R G29L	3.2 3.3	3497	20W	9
SBFN	Fernando D. N.	G12 G30	1.8	193	21W	n.a.
SBFZ	Fortaleza	I13 G31	2.5	82	21W	n.a.
SBMO	Maceio Zumbi	I12 G30	2.6	387	23W	n.a.
SBRF	Recife	I18 G36	3.0	33	22W	9
SBSV	Salvador	I10 I28	3.0	64	23W	8

ICAO	Airport	APP	RWY	ELEV	VAR	RFF
SGAS	Asuncion	G02 I20	3.3	292	12W	9
SBCT	Curitiba	II15 G33	2.2	2989	18W	n.a.
SBPA	Porto Alegre	I11 G29	2.2	11	16W	9
SBGL	Rio de Janeiro	II10 I28 I15 G33	4.0 3.1	28	22W	9
SBGR	Sao Paulo	II09L I27R III09R I27L	3.7 3.0	2459	20W	9
SBKP	Campinas	I15 G33	3.2	2170	20W	9

PORTUGUESE (BRAZIL)	
Good Morning	<bom dia>
Good Afternoon	<bom dia>
Good Evening	<boa tarde>
Good Bye	<até logo>
Thank You	<obrigado>



Brasilia
135.90

Recife
126.10

Brasilia
127.30

Brasilia
123.70

Brasilia
124.70

Curitiba
133.40
135.60

Recife
127.20

Recife
128.70

Recife
128.80

11.5